

- Part Number: 1910
  - Part Title: Occupational Safety and Health Standards
  - Subpart: N
  - Subpart Title: Materials Handling and Storage
  - Standard Number: 1910.179
  - Title: Overhead and gantry cranes.
- 

## Table of Contents

<b>STANDARD</b>	<b>SECTION TITLE</b>	<b>PAGE NO.</b>
1910.179(a)	DEFINITIONS APPLICABLE TO THIS SECTION	2
1910.179(b)	GENERAL REQUIREMENTS	6
1910.179(b)(6)	CLEARANCE FROM OBSTRUCTION	7
1910.179(c)	CABS	8
1910.179(d)	FOOTWALKS AND LADDERS	9
1910.179(e)	STOPS, BUMPERS, RAIL SWEEPS, AND GUARDS	10
1910.179(f)	BRAKES	12
1910.179(g)	ELECTRIC EQUIPMENT	14
1910.179(h)	HOISTING EQUIPMENT	17
1910.179(j)	INSPECTION	19
1910.179(k)	TESTING	21
1910.179(l)	MAINTENANCE	22
1910.179(l)(3)	ADJUSTMENTS AND REPAIRS	23
1910.179(n)	HANDLING THE LOAD	25
1910.179(n)(4)	HOIST LIMIT SWITCH.	27
1910.179(o)	OTHER REQUIREMENTS, GENERAL	27

1910.179(a)

DEFINITIONS APPLICABLE TO THIS SECTION.

**1910.179(a)(1)**

A "crane" is a machine for lifting and lowering a load and moving it horizontally, with the hoisting mechanism an integral part of the machine. Cranes whether fixed or mobile are driven manually or by power.

**1910.179(a)(2)**

An "automatic crane" is a crane which when activated operates through a preset cycle or cycles.

**1910.179(a)(3)**

A "cab-operated crane" is a crane controlled by an operator in a cab located on the bridge or trolley.

**1910.179(a)(4)**

"Cantilever gantry crane" means a gantry or semigantry crane in which the bridge girders or trusses extend transversely beyond the crane runway on one or both sides.

**1910.179(a)(5)**

"Floor-operated crane" means a crane which is pendant or nonconductive rope controlled by an operator on the floor or an independent platform.

**1910.179(a)(6)**

"Gantry crane" means a crane similar to an overhead crane except that the bridge for carrying the trolley or trolleys is rigidly supported on two or more legs running on fixed rails or other runway.

**1910.179(a)(7)**

"Hot metal handling crane" means an overhead crane used for transporting or pouring molten material.

**1910.179(a)(8)**

"Overhead crane" means a crane with a movable bridge carrying a movable or fixed hoisting mechanism and traveling on an overhead fixed runway structure.

**1910.179(a)(9)**

"Power-operated crane" means a crane whose mechanism is driven by electric, air, hydraulic, or internal combustion means.

**1910.179(a)(10)**

A "pulpit-operated crane" is a crane operated from a fixed operator station not attached to the crane.

**1910.179(a)(11)**

A "remote-operated crane" is a crane controlled by an operator not in a pulpit or in the cab attached to the crane, by any method other than pendant or rope control.

**1910.179(a)(12)**

A "semigantry crane" is a gantry crane with one end of the bridge rigidly supported on one or more legs that run on a fixed rail or runway, the other end of the bridge being supported by a truck running on an elevated rail or runway.

**1910.179(a)(13)**

"Storage bridge crane" means a gantry type crane of long span usually used for bulk storage of material; the bridge girders or trusses are rigidly or nonrigidly supported on one or more legs. It may have one or more fixed or hinged cantilever ends.

**1910.179(a)(14)**

"Wall crane" means a crane having a jib with or without trolley and supported from a side wall or line of columns of a building. It is a traveling type and operates on a runway attached to the side wall or columns.

**1910.179(a)(15)**

"Appointed" means assigned specific responsibilities by the employer or the employer's representative.

**1910.179(a)(16)**

"ANSI" means the American National Standards Institute.

**1910.179(a)(17)**

An "auxiliary hoist" is a supplemental hoisting unit of lighter capacity and usually higher speed than provided for the main hoist.

**1910.179(a)(18)**

A "brake" is a device used for retarding or stopping motion by friction or power means.

**1910.179(a)(19)**

A "drag brake" is a brake which provides retarding force without external control.

**1910.179(a)(20)**

A "holding brake" is a brake that automatically prevents motion when power is off.

**1910.179(a)(21)**

"Bridge" means that part of a crane consisting of girders, trucks, end ties, footwalks, and drive mechanism which carries the trolley or trolleys.

**1910.179(a)(22)**

"Bridge travel" means the crane movement in a direction parallel to the crane runway.

**1910.179(a)(23)**

A "bumper" [buffer] is an energy absorbing device for reducing impact when a moving crane or trolley reaches the end of its permitted travel; or when two moving cranes or trolleys come in contact.

**1910.179(a)(24)**

The "cab" is the operator's compartment on a crane.

**1910.179(a)(25)**

"Clearance" means the distance from any part of the crane to a point of the nearest obstruction.

**1910.179(a)(26)**

"Collectors current" are contacting devices for collecting current from runway or bridge conductors.

**1910.179(a)(27)**

"Conductors, bridge" are the electrical conductors located along the bridge structure of a crane to provide power to the trolley.

**1910.179(a)(28)**

"Conductors, runway" [main] are the electrical conductors located along a crane runway to provide power to the crane.

**1910.179(a)(29)**

The "control braking means" is a method of controlling crane motor speed when in an overhauling condition.

**1910.179(a)(30)**

"Countertorque" means a method of control by which the power to the motor is reversed to develop torque in the opposite direction.

**1910.179(a)(31)**

"Dynamic" means a method of controlling crane motor speeds when in the overhauling condition to provide a retarding force.

**1910.179(a)(32)**

"Regenerative" means a form of dynamic braking in which the electrical energy generated is fed back into the power system.

**1910.179(a)(33)**

"Mechanical" means a method of control by friction.

**1910.179(a)(34)**

"Controller, spring return" means a controller which when released will return automatically to a neutral position.

**1910.179(a)(35)**

"Designated" means selected or assigned by the employer or the employer's representative as being qualified to perform specific duties.

**1910.179(a)(36)**

A "drift point" means a point on a travel motion controller which releases the brake while the motor is not energized. This allows for coasting before the brake is set.

**1910.179(a)(37)**

The "drum" is the cylindrical member around which the ropes are wound for raising or lowering the load.

**1910.179(a)(38)**

An "equalizer" is a device which compensates for unequal length or stretch of a rope.

**1910.179(a)(39)**

"Exposed" means capable of being contacted inadvertently. Applied to hazardous objects not adequately guarded or isolated.

**1910.179(a)(40)**

"Fail-safe" means a provision designed to automatically stop or safely control any motion in which a malfunction occurs.

**1910.179(a)(41)**

"Footwalk" means the walkway with handrail, attached to the bridge or trolley for access purposes.

**1910.179(a)(42)**

A "hoist" is an apparatus which may be a part of a crane, exerting a force for lifting or lowering.

**1910.179(a)(43)**

"Hoist chain" means the load bearing chain in a hoist.

NOTE: Chain properties do not conform to those shown in ANSI B30.9-1971, Safety Code for Slings.

**1910.179(a)(44)**

"Hoist motion" means that motion of a crane which raises and lowers a load.

**1910.179(a)(45)**

"Load" means the total superimposed weight on the load block or hook.

**1910.179(a)(46)**

The "load block" is the assembly of hook or shackle, swivel, bearing, sheaves, pins, and frame suspended by the hoisting rope.

**1910.179(a)(47)**

"Magnet" means an electromagnetic device carried on a crane hook to pick up loads magnetically.

**1910.179(a)(48)**

"Main hoist" means the hoist mechanism provided for lifting the maximum rated load.

**1910.179(a)(49)**

A "man trolley" is a trolley having an operator's cab attached thereto.

**1910.179(a)(50)**

"**Rated load**" means the maximum load for which a crane or individual hoist is designed and built by the manufacturer and shown on the equipment nameplate(s).

**1910.179(a)(51)**

"**Rope**" refers to wire rope, unless otherwise specified.

**1910.179(a)(52)**

"**Running sheave**" means a sheave which rotates as the load block is raised or lowered.

**1910.179(a)(53)**

"**Runway**" means an assembly of rails, beams, girders, brackets, and framework on which the crane or trolley travels.

**1910.179(a)(54)**

"**Side pull**" means that portion of the hoist pull acting horizontally when the hoist lines are not operated vertically.

**1910.179(a)(55)**

"**Span**" means the horizontal distance center to center of runway rails.

**1910.179(a)(56)**

"**Standby crane**" means a crane which is not in regular service but which is used occasionally or intermittently as required.

**1910.179(a)(57)**

A "**stop**" is a device to limit travel of a trolley or crane bridge. This device normally is attached to a fixed structure and normally does not have energy absorbing ability.

**1910.179(a)(58)**

A "**switch**" is a device for making, breaking, or for changing the connections in an electric circuit.

**1910.179(a)(59)**

An "**emergency stop switch**" is a manually or automatically operated electric switch to cut off electric power independently of the regular operating controls.

**1910.179(a)(60)**

A "**limit switch**" is a switch which is operated by some part or motion of a power-driven machine or equipment to alter the electric circuit associated with the machine or equipment.

**1910.179(a)(61)**

A "**main switch**" is a switch controlling the entire power supply to the crane.

**1910.179(a)(62)**

A "**master switch**" is a switch which dominates the operation of contactors, relays, or other remotely operated devices.

**1910.179(a)(63)**

The "**trolley**" is the unit which travels on the bridge rails and carries the hoisting mechanism.

**1910.179(a)(64)**

"**Trolley travel**" means the trolley movement at right angles to the crane runway.

**1910.179(a)(65)**

"**Truck**" means the unit consisting of a frame, wheels, bearings, and axles which supports the bridge girders or trolleys.

1910.179(b)  
GENERAL REQUIREMENTS

**1910.179(b)(1)**

**Application.** This section applies to overhead and gantry cranes, including semigantry, cantilever gantry, wall cranes, storage bridge cranes, and others having the same fundamental characteristics. These cranes are grouped because they all have trolleys and similar travel characteristics.

**1910.179(b)(2)**

**New and existing equipment.** All new overhead and gantry cranes constructed and installed on or after August 31, 1971, **shall** meet the design specifications of the American National Standard Safety Code for Overhead and Gantry Cranes, ANSI B30.2.0-1967, which is incorporated by reference as specified in Sec. 1910.6.

**1910.179(b)(3)**

**Modifications.** Cranes may be modified and rerated provided such modifications and the supporting structure are checked thoroughly for the new rated load by a qualified engineer or the equipment manufacturer. The crane **shall** be tested in accordance with paragraph (k) (2) of this section. New rated load **shall** be displayed in accordance with subparagraph (5) of this paragraph.

**1910.179(b)(4)**

**Wind indicators and rail clamps.** Outdoor storage bridges **shall** be provided with automatic rail clamps. A wind-indicating device **shall** be provided which will give a visible or audible alarm to the bridge operator at a predetermined wind velocity. If the clamps act on the rail heads, any beads or weld flash on the rail heads **shall** be ground off.

**1910.179(b)(5)**

**Rated load marking.** The rated load of the crane **shall** be plainly marked on each side of the crane, and if the crane has more than one hoisting unit, each hoist **shall** have its rated load marked on it or its load block and this marking **shall** be clearly legible from the ground or floor.

1910.179(b)(6)

CLEARANCE FROM OBSTRUCTION

**1910.179(b)(6)(i)**

**Minimum clearance** of 3 inches overhead and 2 inches laterally **shall** be provided and maintained between crane and obstructions in conformity with Crane Manufacturers Association of America, Inc, Specification No. 61, which is incorporated by reference as specified in Sec. 1910.6, (formerly the Electric Overhead Crane Institute, Inc).

**1910.179(b)(6)(ii)**

Where **passageways or walkways** are provided obstructions **shall** not be placed so that safety of personnel will be jeopardized by movements of the crane.

**1910.179(b)(7)**

**Clearance between parallel cranes.** If the runways of two cranes are parallel, and there are no intervening walls or structure, there **shall** be adequate clearance provided and maintained between the two bridges.

**1910.179(b)(8)**

**Designated personnel** - Only designated personnel **shall** be permitted to operate a crane covered by this section.

1910.179(c)  
CABS

**1910.179(c)(1)**

**Cab location.**

**1910.179(c)(1)(i)**

The general arrangement of the cab and the location of control and protective equipment **shall** be such that all operating handles are within convenient reach of the operator when facing the area to be served by the load hook, or while facing the direction of travel of the cab. The arrangement **shall** allow the operator a full view of the load hook in all positions.

**1910.179(c)(1)(ii)**

The cab **shall** be located to afford a minimum of 3 inches clearance from all fixed structures within its area of possible movement.

**1910.179(c)(2)**

**Access to crane.** Access to the cab and/or bridge walkway **shall** be by a conveniently placed fixed ladder, stairs, or platform requiring no step over any gap exceeding 12 inches. Fixed ladders **shall** be in conformance with the American National Standard Safety Code for Fixed Ladders, ANSI A14.3-1956, which is incorporated by reference as specified in Sec. 1910.6.

**1910.179(c)(3)**

**Fire extinguisher.** Carbon tetrachloride extinguishers **shall** not be used.

**1910.179(c)(4)**

**Lighting.** Light in the cab **shall** be sufficient to enable the operator to see clearly enough to perform his work.

1910.179(d)  
FOOTWALKS AND LADDERS

**1910.179(d)(1)**

**Location of footwalks.**

**1910.179(d)(1)(i)**

If sufficient headroom is available on cab-operated cranes, a footwalk shall be provided on the drive side along the entire length of the bridge of all cranes having the trolley running on the top of the girders.

**1910.179(d)(1)(ii)**

Where footwalks are located in no case shall less than 48 inches of headroom be provided.

**1910.179(d)(2)**

**Construction of footwalks.**

**1910.179(d)(2)(i)**

Footwalks shall be of rigid construction and designed to sustain a distributed load of at least 50 pounds per square foot.

**1910.179(d)(2)(ii)**

Footwalks shall have a walking surface of antislip type.

NOTE: Wood will meet this requirement.

**1910.179(d)(2)(iii)**

[Reserved]

**1910.179(d)(2)(iv)**

The inner edge shall extend at least to the line of the outside edge of the lower cover plate or flange of the girder.

**1910.179(d)(3)**

Toeboards and handrails for footwalks. Toeboards and handrails shall be in compliance with section 1910.23 of this part.

**1910.179(d)(4)**

**Ladders and stairways.**

**1910.179(d)(4)(i)**

Gantry cranes shall be provided with ladders or stairways extending from the ground to the footwalk or cab platform.

**1910.179(d)(4)(ii)**

Stairways shall be equipped with rigid and substantial metal handrails. Walking surfaces shall be of an antislip type.

**1910.179(d)(4)(iii)**

Ladders shall be permanently and securely fastened in place and shall be constructed in compliance with 1910.27.

1910.179(e)  
STOPS, BUMPERS, RAIL SWEEPS, AND GUARDS

**1910.179(e)(1)**

**Trolley stops.**

**1910.179(e)(1)(i)**

Stops **shall** be provided at the limits of travel of the trolley.

**1910.179(e)(1)(ii)**

Stops **shall** be fastened to resist forces applied when contacted.

**1910.179(e)(1)(iii)**

A stop engaging the tread of the wheel **shall** be of a height at least equal to the radius of the wheel.

**1910.179(e)(2)**

**Bridge bumpers -**

**1910.179(e)(2)(i)**

A crane **shall** be provided with bumpers or other automatic means providing equivalent effect, unless the crane travels at a slow rate of speed and has a faster deceleration rate due to the use of sleeve bearings, or is not operated near the ends of bridge and trolley travel, or is restricted to a limited distance by the nature of the crane operation and there is no hazard of striking any object in this limited distance, or is used in similar operating conditions. The bumpers **shall** be capable of stopping the crane (not including the lifted load) at an average rate of deceleration not to exceed 3 ft/s/s when traveling in either direction at 20 percent of the rated load speed.

**1910.179(e)(2)(i)(a)**

The bumpers **shall** have sufficient energy absorbing capacity to stop the crane when traveling at a speed of at least 40 percent of rated load speed.

**1910.179(e)(2)(i)(b)**

The bumper **shall** be so mounted that there is no direct shear on bolts.

**1910.179(e)(2)(ii)**

Bumpers **shall** be so designed and installed as to minimize parts falling from the crane in case of breakage.

**1910.179(e)(3)**

**Trolley bumpers -**

**1910.179(e)(3)(i)**

A trolley **shall** be provided with bumpers or other automatic means of equivalent effect, unless the trolley travels at a slow rate of speed, or is not operated near the ends of bridge and trolley travel, or is restricted to a limited distance of the runway and there is no hazard of striking any object in this limited distance, or is used in similar operating conditions. The bumpers **shall** be capable of stopping the trolley (not including the lifted load) at an average rate of deceleration not to exceed 4.7 ft/s/s when traveling in either direction at one-third of the rated load speed.

**1910.179(e)(3)(ii)**

When more than one trolley is operated on the same bridge, each **shall** be equipped with bumpers or equivalent on their adjacent ends.

**1910.179(e)(3)(iii)**

Bumpers or equivalent **shall** be designed and installed to minimize parts falling from the trolley in case of age.

**1910.179(e)(4)**

**Rail sweeps.** Bridge trucks **shall** be equipped with sweeps which extend below the top of the rail and project in front of the truck wheels.

**1910.179(e)(5)**

**Guards for hoisting ropes.**

**1910.179(e)(5)(i)**

**If hoisting ropes run near enough to other parts** to make fouling or chafing possible, guards **shall** be installed to prevent this condition.

**1910.179(e)(5)(ii)**

A **guard shall** be provided to prevent contact between bridge conductors and hoisting ropes if they could come into contact.

**1910.179(e)(6)**

**Guards for moving parts.**

**1910.179(e)(6)(i)**

**Exposed moving parts** such as gears, set screws, projecting keys, chains, chain sprockets, and reciprocating components which might constitute a hazard under normal operating conditions **shall** be guarded.

**1910.179(e)(6)(ii)**

**Guards shall** be securely fastened.

**1910.179(e)(6)(iii)**

**Each guard shall** be capable of supporting without permanent distortion the weight of a 200-pound person unless the guard is located where it is impossible for a person to step on it.

1910.179(f)  
BRAKES

**1910.179(f)(1)**

**Brakes for hoists.**

**1910.179(f)(1)(i)**

Each independent hoisting unit of a crane shall be equipped with at least one self-setting brake, hereafter referred to as a holding brake, applied directly to the motor shaft or some part of the gear train.

**1910.179(f)(1)(ii)**

Each independent hoisting unit of a crane, except worm-gear hoists, the angle of whose worm is such as to prevent the load from accelerating in the lowering direction shall, in addition to a holding brake, be equipped with control braking means to prevent overspeeding.

**1910.179(f)(2)**

**Holding brakes.**

**1910.179(f)(2)(i)**

Holding brakes for hoist motors shall have not less than the following percentage of the full load hoisting torque at the point where the brake is applied.

**1910.179(f)(2)(i)(a)**

125 percent when used with a control braking means other than mechanical.

**1910.179(f)(2)(i)(b)**

100 percent when used in conjunction with a mechanical control braking means.

**1910.179(f)(2)(i)(c)**

100 percent each if two holding brakes are provided.

**1910.179(f)(2)(ii)**

Holding brakes on hoists shall have ample thermal capacity for the frequency of operation required by the service.

**1910.179(f)(2)(iii)**

Holding brakes on hoists shall be applied automatically when power is removed.

**1910.179(f)(2)(iv)**

Where necessary holding brakes shall be provided with adjustment means to compensate for wear.

**1910.179(f)(2)(v)**

The wearing surface of all holding-brake drums or discs shall be smooth.

**1910.179(f)(2)(vi)**

Each independent hoisting unit of a crane handling hot metal and having power control braking means shall be equipped with at least two holding brakes.

**1910.179(f)(3)**

**Control braking means.**

**1910.179(f)(3)(i)**

A power control braking means such as regenerative, dynamic or countertorque braking, or a mechanically controlled braking means shall be capable of maintaining safe lowering speeds of rated loads.

**1910.179(f)(3)(ii)**

The control braking means shall have ample thermal capacity for the frequency of operation required by service.

**1910.179(f)(4)**

**Brakes for trolleys and bridges.**

**1910.179(f)(4)(i)**

**Foot-operated brakes shall** not require an applied force of more than 70 pounds to develop manufacturer's rated brake torque.

**1910.179(f)(4)(ii)**

**Brakes** may be applied by mechanical, electrical, pneumatic, hydraulic, or gravity means.

**1910.179(f)(4)(iii)**

Where necessary brakes **shall** be provided with adjustment means to compensate for wear.

**1910.179(f)(4)(iv)**

**The wearing surface of all brakedrums or discs shall** be smooth.

**1910.179(f)(4)(v)**

**All foot-brake pedals shall** be constructed so that the operator's foot will not easily slip off the pedal.

**1910.179(f)(4)(vi)**

**Foot-operated brakes shall** be equipped with automatic means for positive release when pressure is released from the pedal.

**1910.179(f)(4)(vii)**

**Brakes for stopping** the motion of the trolley or bridge **shall** be of sufficient size to stop the trolley or bridge within a distance in feet equal to 10 percent of full load speed in feet per minute when traveling at full speed with full load.

**1910.179(f)(4)(viii)**

**If holding brakes are provided** on the bridge or trolleys, they **shall** not prohibit the use of a drift point in the control circuit.

**1910.179(f)(4)(ix)**

**Brakes on trolleys and bridges shall** have ample thermal capacity for the frequency of operation required by the service to prevent impairment of functions from overheating.

**1910.179(f)(5)**

**Application of trolley brakes.**

**1910.179(f)(5)(i)**

On **cab-operated cranes with cab on trolley**, a trolley brake **shall** be required as specified under paragraph (f)(4) of this section.

**1910.179(f)(5)(ii)**

A **drag brake** may be applied to hold the trolley in a desired position on the bridge and to eliminate creep with the power off.

**1910.179(f)(6)**

**Application of bridge brakes.**

**1910.179(f)(6)(i)**

On **cab-operated cranes with cab on bridge**, a bridge brake is required as specified under paragraph (f)(4) of this section.

**1910.179(f)(6)(ii)**

On **cab-operated cranes with cab on trolley**, a bridge brake of the holding type **shall** be required.

**1910.179(f)(6)(iii)**

On **all floor, remote and pulpit-operated crane bridge drives**, a brake of noncoasting mechanical drive **shall** be provided.

**1910.179(g)**  
**ELECTRIC EQUIPMENT**

**1910.179(g)(1)**

**General.**

**1910.179(g)(1)(i)**

**Wiring and equipment shall** comply with subpart S of this part.

**1910.179(g)(1)(ii)**

**The control circuit voltage shall** not exceed 600 volts for a.c. or d.c. current.

**1910.179(g)(1)(iii)**

**The voltage at pendant push-buttons shall** not exceed 150 volts for a.c. and 300 volts for d.c.

**1910.179(g)(1)(iv)**

**Where multiple conductor cable is used with a suspended pushbutton station**, the station must be supported in some satisfactory manner that will protect the electrical conductors against strain.

**1910.179(g)(1)(v)**

**Pendant control boxes shall** be constructed to prevent electrical shock and shall be clearly marked for identification of functions.

**1910.179(g)(2)**

**Equipment.**

**1910.179(g)(2)(i)**

**Electrical equipment shall** be so located or enclosed that live parts will not be exposed to accidental contact under normal operating conditions.

**1910.179(g)(2)(ii)**

**Electric equipment shall** be protected from dirt, grease, oil, and moisture.

**1910.179(g)(2)(iii)**

**Guards for live parts shall** be substantial and so located that they cannot be accidentally deformed so as to make contact with the live parts.

**1910.179(g)(3)**

**Controllers.**

**1910.179(g)(3)(i)**

**Cranes not equipped with spring-return controllers or momentary contact pushbuttons shall** be provided with a device which will disconnect all motors from the line on failure of power and will not permit any motor to be restarted until the controller handle is brought to the "off" position, or a reset switch or button is operated.

**1910.179(g)(3)(ii)**

**Lever operated controllers shall** be provided with a notch or latch which in the "off" position prevents the handle from being inadvertently moved to the "on" position. An "off" detent or spring return arrangement is acceptable.

**1910.179(g)(3)(iii)**

The controller operating handle **shall** be located within convenient reach of the operator.

**1910.179(g)(3)(iv)**

As far as practicable, the **movement of each controller handle shall** be in the same general directions as the resultant movements of the load.

**1910.179(g)(3)(v)**

**The control for the bridge and trolley travel shall** be so located that the operator can

readily face the direction of travel.

**1910.179(g)(3)(vi)**

For **floor-operated cranes**, the controller or controllers if rope operated, **shall** automatically return to the "off" position when released by the operator.

**1910.179(g)(3)(vii)**

**Pushbuttons in pendant stations shall** return to the "off" position when pressure is released by the crane operator.

**1910.179(g)(3)(viii)**

**Automatic cranes shall** be so designed that all motions shall fail-safe if any malfunction of operation occurs.

**1910.179(g)(3)(ix)**

**Remote-operated cranes shall** function so that if the control signal for any crane motion becomes ineffective the crane motion shall stop.

**1910.179(g)(4)**

**Resistors.**

**1910.179(g)(4)(i)**

**Enclosures for resistors shall** have openings to provide adequate ventilation, and shall be installed to prevent the accumulation of combustible matter too near to hot parts.

**1910.179(g)(4)(ii)**

**Resistor units shall** be supported so as to be as free as possible from vibration.

**1910.179(g)(4)(iii)**

**Provision shall** be made to prevent broken parts or molten metal falling upon the operator or from the crane.

**1910.179(g)(5)**

**Switches.**

**1910.179(g)(5)(i)**

**The power supply to the runway conductors shall** be controlled by a switch or circuit breaker located on a fixed structure, accessible from the floor, and arranged to be locked in the open position.

**1910.179(g)(5)(ii)**

**On cab-operated cranes** a switch or circuit breaker of the enclosed type, with provision for locking in the open position, **shall** be provided in the leads from the runway conductors. A means of opening this switch or circuit breaker shall be located within easy reach of the operator.

**1910.179(g)(5)(iii)**

**On floor-operated cranes**, a switch or circuit breaker of the enclosed type, with provision for locking in the open position, **shall** be provided in the leads from the runway conductors. This disconnect shall be mounted on the bridge or footwalk near the runway collectors. One of the following types of floor-operated disconnects shall be provided:

**1910.179(g)(5)(iii)(a)**

**Nonconductive rope** attached to the main disconnect switch.

**1910.179(g)(5)(iii)(b)**

**An undervoltage trip** for the main circuit breaker operated by an emergency stop button in the pendant pushbutton in the pendant pushbutton station.

**1910.179(g)(5)(iii)(c)**

**A main line contactor** operated by a switch or pushbutton in the pendant pushbutton

station.

**1910.179(g)(5)(iv)**

**The hoisting motion** of all electric traveling cranes **shall** be provided with an overtravel limit switch in the hoisting direction.

**1910.179(g)(5)(v)**

**All cranes using a lifting magnet shall** have a magnet circuit switch of the enclosed type with provision for locking in the open position. Means for discharging the inductive load of the magnet shall be provided.

**1910.179(g)(6)**

**Runway conductors.** Conductors of the open type mounted on the crane runway beams or overhead **shall** be so located or so guarded that persons entering or leaving the cab or crane footwalk normally could not come into contact with them.

**1910.179(g)(7)**

**Extension lamps.** If a service receptacle is provided in the cab or on the bridge of cab-operated cranes, it **shall** be a grounded three-prong type permanent receptacle, not exceeding 300 volts.

1910.179(h)  
HOISTING EQUIPMENT

**1910.179(h)(1)**

**Sheaves.**

**1910.179(h)(1)(i)**

**Sheave grooves shall** be smooth and free from surface defects which could cause rope damage.

**1910.179(h)(1)(ii)**

**Sheaves carrying ropes which can be momentarily unloaded shall** be provided with close-fitting guards or other suitable devices to guide the rope back into the groove when the load is applied again.

**1910.179(h)(1)(iii)**

**The sheaves in the bottom block shall** be equipped with close-fitting guards that will prevent ropes from becoming fouled when the block is lying on the ground with ropes loose.

**1910.179(h)(1)(iv)**

**Pockets and flanges of sheaves used with hoist chains shall** be of such dimensions that the chain does not catch or bind during operation.

**1910.179(h)(1)(v)**

**All running sheaves shall** be equipped with means for lubrication. Permanently lubricated, sealed and/or shielded bearings meet this requirement.

**1910.179(h)(2)**

**Ropes.**

**1910.179(h)(2)(i)**

**In using hoisting ropes,** the crane manufacturer's recommendation **shall** be followed. The rated load divided by the number of parts of rope shall not exceed 20 percent of the nominal breaking strength of the rope.

**1910.179(h)(2)(ii)**

**Socketing shall** be done in the manner specified by the manufacturer of the assembly.

**1910.179(h)(2)(iii)**

Rope shall be secured to the drum as follows:

**1910.179(h)(2)(iii)(a)**

**No less than two wraps of rope shall** remain on the drum when the hook is in its extreme low position.

**1910.179(h)(2)(iii)(b)**

**Rope end shall** be anchored by a clamp securely attached to the drum, or by a socket arrangement approved by the crane or rope manufacturer.

**1910.179(h)(2)(iv)**

**Eye splices. [Reserved]**

**1910.179(h)(2)(v)**

**Rope clips attached with U-bolts** shall have the U-bolts on the dead or short end of the rope. Spacing and number of all types of clips shall be in accordance with the clip manufacturer's recommendation. Clips **shall** be drop-forged steel in all sizes manufactured commercially. When a newly installed rope has been in operation for an hour, all nuts on the clip bolts shall be retightened.

**1910.179(h)(2)(vi)**

**Swaged or compressed fittings shall** be applied as recommended by the rope or crane

manufacturer.

**1910.179(h)(2)(vii)**

**Wherever exposed to temperatures**, at which fiber cores would be damaged, rope having an independent wirerope or wire-strand core, or other temperature-damage resistant core **shall** be used.

**1910.179(h)(2)(viii)**

**Replacement rope shall** be the same size, grade, and construction as the original rope furnished by the crane manufacturer, unless otherwise recommended by a wire rope manufacturer due to actual working condition requirements.

**1910.179(h)(3)**

**Equalizers.** If a load is supported by more than one part of rope, the tension in the parts **shall** be equalized.

**1910.179(h)(4)**

**Hooks.** Hooks **shall** meet the manufacturer's recommendations and shall not be overloaded.

**1910.179(i)**

**Warning device.** Except for floor-operated cranes a gong or other effective warning signal **shall** be provided for each crane equipped with a power traveling mechanism.

1910.179(j)  
INSPECTION

**1910.179(j)(1)**

**Inspection classification.**

**1910.179(j)(1)(i)**

**Initial inspection.** Prior to initial use all new and altered cranes **shall** be inspected to insure compliance with the provisions of this section.

**1910.179(j)(1)(ii)**

**Inspection procedure for cranes in regular service** is divided into two general classifications based upon the intervals at which inspection should be performed. The intervals in turn are dependent upon the nature of the critical components of the crane and the degree of their exposure to wear, deterioration, or malfunction. The two general classifications are herein designated as "frequent" and "periodic" with respective intervals between inspections as defined below:

**1910.179(j)(1)(ii)(a)**

**Frequent inspection** - Daily to monthly intervals.

**1910.179(j)(1)(ii)(b)**

**Periodic inspection** - 1 to 12-month intervals.

**1910.179(j)(2)**

**Frequent inspection. The following items shall be inspected** for defects at intervals as defined in paragraph (j)(1)(ii) of this section or as specifically indicated, including observation during operation for any defects which might appear between regular inspections. All deficiencies such as listed shall be carefully examined and determination made as to whether they constitute a safety hazard:

**1910.179(j)(2)(i)**

**All functional operating mechanisms** for maladjustment interfering with proper operation. Daily.

**1910.179(j)(2)(ii)**

**Deterioration or leakage in lines, tanks, valves, drain pumps,** and other parts of air or hydraulic systems. Daily.

**1910.179(j)(2)(iii)**

**Hooks with deformation or cracks.** Visual inspection daily; monthly inspection with a certification record which includes the date of inspection, the signature of the person who performed the inspection and the serial number, or other identifier, of the hook inspected. For hooks with cracks or having more than 15 percent in excess of normal throat opening or more than 10° twist from the plane of the unbent hook refer to paragraph (l)(3)(iii)(a) of this section.

**1910.179(j)(2)(iv)**

**Hoist chains,** including end connections, for excessive wear, twist, distorted links interfering with proper function, or stretch beyond manufacturer's recommendations. Visual inspection daily; monthly inspection with a certification record which includes the date of inspection, the signature of the person who performed the inspection and an identifier of the chain which was inspected.

**1910.179(j)(2)(v)**

[Reserved]

**1910.179(j)(2)(vi)**

**All functional operating mechanisms** for excessive wear of components.

**1910.179(j)(2)(vii)**

**Rope reeving** for noncompliance with manufacturer's recommendations.

**1910.179(j)(3)**

**Periodic inspection.** Complete inspections of the crane **shall** be performed at intervals as generally defined in paragraph (j)(1)(ii)(b) of this section, depending upon its activity, severity of service, and environment, or as specifically indicated below. These inspections **shall** include the requirements of paragraph (j)(2) of this section and in addition, the following items. Any deficiencies such as listed **shall** be carefully examined and determination made as to whether they constitute a safety hazard:

**1910.179(j)(3)(i)**

Deformed, cracked, or corroded members.

**1910.179(j)(3)(ii)**

Loose bolts or rivets.

**1910.179(j)(3)(iii)**

Cracked or worn sheaves and drums.

**1910.179(j)(3)(iv)**

Worn, cracked or distorted parts such as pins, bearings, shafts, gears, rollers, locking and clamping devices.

**1910.179(j)(3)(v)**

Excessive wear on brake system parts, linings, pawls, and ratchets.

**1910.179(j)(3)(vi)**

Load, wind, and other indicators over their full range, for any significant inaccuracies.

**1910.179(j)(3)(vii)**

Gasoline, diesel, electric, or other powerplants for improper performance or noncompliance with applicable safety requirements.

**1910.179(j)(3)(viii)**

Excessive wear of chain drive sprockets and excessive chain stretch.

**1910.179(j)(3)(ix)**

[Reserved]

**1910.179(j)(3)(x)**

Electrical apparatus, for signs of pitting or any deterioration of controller contactors, limit switches and pushbutton stations.

**1910.179(j)(4)**

**Cranes not in regular use.**

**1910.179(j)(4)(i)**

**A crane which has been idle for a period of 1 month or more, but less than 6 months, shall** be given an inspection conforming with requirements of paragraph (j)(2) of this section and paragraph (m)(2) of this section before placing in service.

**1910.179(j)(4)(ii)**

**A crane which has been idle for a period of over 6 months shall** be given a complete inspection conforming with requirements of paragraphs (j)(2) and (3) of this section and paragraph (m)(2) of this section before placing in service.

**1910.179(j)(4)(iii)**

**Standby cranes shall** be inspected at least semi-annually in accordance with requirements of paragraph (j)(2) of this section and paragraph (m)(2) of this section.

1910.179(k)  
TESTING

**1910.179(k)(1)**

**Operational tests.**

**1910.179(k)(1)(i)**

**Prior to initial use** all new and altered cranes **shall** be tested to insure compliance with this section including the following functions:

**1910.179(k)(1)(i)(a)**

**Hoisting and lowering.**

**1910.179(k)(1)(i)(b)**

**Trolley travel.**

**1910.179(k)(1)(i)(c)**

**Bridge travel.**

**1910.179(k)(1)(i)(d)**

**Limit switches, locking and safety devices.**

**1910.179(k)(1)(ii)**

**The trip setting of hoist limit switches shall** be determined by tests with an empty hook traveling in increasing speeds up to the maximum speed. The actuating mechanism of the limit switch shall be located so that it will trip the switch, under all conditions, in sufficient time to prevent contact of the hook or hook block with any part of the trolley.

**1910.179(k)(2)**

**Rated load test.** Test loads **shall** not be more than 125 percent of the rated load unless otherwise recommended by the manufacturer. The test reports shall be placed on file where readily available to appointed personnel.

1910.179(l)  
MAINTENANCE

**1910.179(l)(1)**

**Preventive maintenance.** A preventive maintenance program based on the crane manufacturer's recommendations **shall** be established.

**1910.179(l)(2)**

**Maintenance procedure.**

**1910.179(l)(2)(i)**

**Before adjustments and repairs are started** on a crane the following precautions **shall** be taken:

**1910.179(l)(2)(i)(a)**

**The crane to be repaired shall** be run to a location where it will cause the least interference with other cranes and operations in the area.

**1910.179(l)(2)(i)(b)**

**All controllers shall** be at the off position.

**1910.179(l)(2)(i)(c)**

**The main or emergency switch shall** be open and locked in the open position.

**1910.179(l)(2)(i)(d)**

**Warning or "out of order" signs shall** be placed on the crane, also on the floor beneath or on the hook where visible from the floor.

**1910.179(l)(2)(i)(e)**

**Where other cranes are in operation on the same runway, rail stops or other suitable means shall** be provided to prevent interference with the idle crane.

**1910.179(l)(2)(ii)**

**After adjustments and repairs have been made** the crane **shall** not be operated until all guards have been reinstalled, safety devices reactivated and maintenance equipment removed.

1910.179(l)(3)  
ADJUSTMENTS AND REPAIRS

**1910.179(l)(3)(i)**

Any **unsafe conditions** disclosed by the inspection requirements of paragraph (j) of this section **shall** be corrected before operation of the crane is resumed. **Adjustments and repairs shall be done** only by designated personnel.

**1910.179(l)(3)(ii)**

**Adjustments shall** be maintained to assure correct functioning of components. The following are examples:

**1910.179(l)(3)(ii)(a)**

**All functional operating mechanisms.**

**1910.179(l)(3)(ii)(b)**

**Limit switches.**

**1910.179(l)(3)(ii)(c)**

**Control systems.**

**1910.179(l)(3)(ii)(d)**

**Brakes.**

**1910.179(l)(3)(ii)(e)**

**Power plants.**

**1910.179(l)(3)(iii)**

**Repairs or replacements shall** be provided promptly as needed for safe operation. The following are examples:

**1910.179(l)(3)(iii)(a)**

**Crane hooks** showing defects described in paragraph (j)(2)(iii) of this section **shall** be discarded. Repairs by welding or reshaping are not generally recommended. If such repairs are attempted they **shall** only be done under competent supervision and the hook **shall** be tested to the load requirements of paragraph (k)(2) of this section before further use.

**1910.179(l)(3)(iii)(b)**

**Load attachment chains and rope slings** showing defects described in paragraph (j)(2)(iv) and (v) of this section respectively.

**1910.179(l)(3)(iii)(c)**

**All critical parts** which are cracked, broken, bent, or excessively worn.

**1910.179(l)(3)(iii)(d)**

**Pendant control stations shall** be kept clean and function labels kept legible.

**1910.179(m)**

**Rope inspection. -**

**1910.179(m)(1)**

**Running ropes.** A thorough inspection of all ropes shall be made at least once a month and a certification record which includes the date of inspection, the signature of the person who performed the inspection and an identifier for the ropes which were inspected shall be kept on file where readily available to appointed personnel. Any deterioration, resulting in appreciable loss of original strength, shall be carefully observed and determination made as to whether further use of the rope would constitute a safety hazard. Some of the conditions that could result in an appreciable loss of strength are the following:

**1910.179(m)(1)(i)**

**Reduction of rope diameter** below nominal diameter due to loss of core support, internal or external corrosion, or wear of outside wires.

**1910.179(m)(1)(ii)**

A number of broken outside wires and the degree of distribution or concentration of such broken wires.

**1910.179(m)(1)(iii)**

Worn outside wires.

**1910.179(m)(1)(iv)**

Corroded or broken wires at end connections.

**1910.179(m)(1)(v)**

Corroded, cracked, bent, worn, or improperly applied end connections.

**1910.179(m)(1)(vi)**

Severe kinking, crushing, cutting, or unstranding.

**1910.179(m)(2)**

**Other ropes.** All rope which has been idle for a period of a month or more due to shutdown or storage of a crane on which it is installed **shall** be given a thorough inspection before it is used. This inspection shall be for all types of deterioration and **shall** be performed by an appointed person whose approval shall be required for further use of the rope. A certification record **shall** be available for inspection which includes the date of inspection, the signature of the person who performed the inspection and an identifier for the rope which was inspected.

1910.179(n)  
HANDLING THE LOAD

**1910.179(n)(1)**

**Size of load.** The crane **shall** not be loaded beyond its rated load except for test purposes as provided in paragraph (k) of this section.

**1910.179(n)(2)**

**Attaching the load.**

**1910.179(n)(2)(i)**

**The hoist chain or hoist rope shall** be free from kinks or twists and shall not be wrapped around the load.

**1910.179(n)(2)(ii)**

**The load shall** be attached to the load block hook by means of slings or other approved devices.

**1910.179(n)(2)(iii)**

**Care shall** be taken to make certain that the sling clears all obstacles.

**1910.179(n)(3)**

**Moving the load.**

**1910.179(n)(3)(i)**

**The load shall** be well secured and properly balanced in the sling or lifting device before it is lifted more than a few inches.

**1910.179(n)(3)(ii)**

**Before starting to hoist** the following conditions **shall** be noted:

**1910.179(n)(3)(ii)(a)**

**Hoist rope shall** not be kinked.

**1910.179(n)(3)(ii)(b)**

**Multiple part lines shall** not be twisted around each other.

**1910.179(n)(3)(ii)(c)**

**The hook shall** be brought over the load in such a manner as to prevent swinging.

**1910.179(n)(3)(iii)**

**During hoisting** care shall be taken that:

**1910.179(n)(3)(iii)(a)**

There is no sudden acceleration or deceleration of the moving load.

**1910.179(n)(3)(iii)(b)**

**The load** does not contact any obstructions.

**1910.179(n)(3)(iv)**

**Cranes shall** not be used for side pulls except when specifically authorized by a responsible person who has determined that the stability of the crane is not thereby endangered and that various parts of the crane will not be overstressed.

**1910.179(n)(3)(v)**

**While any employee is on the load or hook,** there **shall** be no hoisting, lowering, or traveling.

**1910.179(n)(3)(vi)**

**The employer shall** require that the operator avoid carrying loads over people.

**1910.179(n)(3)(vii)**

**The operator shall** test the brakes each time a load approaching the rated load is handled. The brakes shall be tested by raising the load a few inches and applying the brakes.

**1910.179(n)(3)(viii)**

The load **shall** not be lowered below the point where less than two full wraps of rope remain on the hoisting drum.

**1910.179(n)(3)(ix)**

When two or more cranes are used to lift a load one qualified responsible person **shall** be in charge of the operation. He shall analyze the operation and instruct all personnel involved in the proper positioning, rigging of the load, and the movements to be made.

**1910.179(n)(3)(x)**

The employer **shall** insure that the operator does not leave his position at the controls while the load is suspended.

**1910.179(n)(3)(xi)**

When starting the bridge and when the load or hook approaches near or over personnel, the warning signal shall be sounded.

**1910.179(n)(4)**  
**HOIST LIMIT SWITCH.**

**1910.179(n)(4)(i)**

At the beginning of each operator's shift, the upper limit switch of each hoist **shall** be tried out under no load. Extreme care shall be exercised; the block shall be "inched" into the limit or run in at slow speed. If the switch does not operate properly, the appointed person **shall** be immediately notified.

**1910.179(n)(4)(ii)**

The hoist limit switch which controls the upper limit of travel of the load block **shall** never be used as an operating control.

**1910.179(o)**  
**OTHER REQUIREMENTS, GENERAL**

**1910.179(o)(1)**

**Ladders.**

**1910.179(o)(1)(i)**

The employer **shall** insure that hands are free from encumbrances while personnel are using ladders.

**1910.179(o)(1)(ii)**

Articles which are too large to be carried in pockets or belts **shall** be lifted and lowered by hand line.

**1910.179(o)(2)**

**Cabs.**

**1910.179(o)(2)(i)**

Necessary clothing and personal belongings **shall** be stored in such a manner as not to interfere with access or operation.

**1910.179(o)(2)(ii)**

Tools, oil cans, waste, extra fuses, and other necessary articles **shall** be stored in the tool box, and shall not be permitted to lie loose in or about the cab.

**1910.179(o)(3)**

**Fire extinguishers.** The employer **shall** insure that operators are familiar with the operation and care of the fire extinguishers provided.

[39 FR 23502, June 27, 1974, as amended at 40 FR 27400, June 27, 1975; 49 FR 5322, Feb. 10, 1984; 51 FR 34560, Sept. 29, 1986; 55 FR 32015, Aug. 6, 1990; 61 FR 9227, March 7, 1996]